



# Adapter List 2013

Model	EU Adapter	UK Adapter	US Adapter	Comments
Adventurer	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Adventurer SL	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Adventurer Pro	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
AP	00087925	00089405	00088668	Line Cord
AS	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)	Power Adapter
AS142	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Aviator	46001802 + 46001779	46001802 + 46001779	46001802 + 46001779	Universal Adapter + Plug Set
BC	<b>Snr &lt; 8033071417 or Old PCB:</b> 80120001 <b>New PCB or Snr &gt; 8033071417:</b> 46001812 + 46001779	<b>Snr &lt; 8033071417 or Old PCB:</b> 80120002 <b>New PCB or Snr &gt; 8033071417:</b> 46001812 + 46001779	<b>Snr &lt; 8033071417 or Old PCB:</b> 80120000 <b>New PCB or Snr &gt; 8033071417:</b> 46001812 + 46001780	Universal Adapter + Plug Set
Brainweigh	00087925	00089405	00088668	Line Cord
BW Series	46001810 + 46001779	46001810 + 46001779	46001810 + 46001780	Universal Adapter + Plug Set
C Series (Port-O-Gram)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Catapult 1000	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
CBM910	80252038 (EU)	-	-	Power Adapter
CD1	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
CD11	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
CD31 / CD33	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
CKW	71172177	71172930	71209118	Line Cord
CL	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
CS (OLD)	80500458 (obsolete)	80500459 (obsolete)	80500457 (obsolete)	Has Cal/Unit Key
CS (Current)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
CT	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
CW11	71134043	71134148	71134042	Line Cord
DA / DC / DP	21250113	21250114	21250115	Power Adapter
Defender 2000 (T21P)	46001812 + 46001779	46001812 + 46001779	46001812 + 46001780	Universal Adapter + Plug Set
Defender 2000 (T23P)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
Defender 3000 (T31P, D22Mx, T32Mx)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
Defender 3000 (T3*XW)	72200234	72200236	72200237	Line Cord

For additional assistance please contact [tsc@ohaus.com](mailto:tsc@ohaus.com)

Part numbers are subject to change without notice



# Adapter List 2013

Defender 5000 (T51P)	72200229	72200231	72200232	Line Cord
Defender 5000 (T51XW)	72200234	72200236	72200237	Line Cord
Defender 7000 (T71P)	72200229	72200231	72200232	Line Cord
Defender 7000 (T71XW)	72200234	72200236	72200237	Line Cord
Diamond (JDxxxx)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Discovery	30006112 + 00087925	30006112 + 00089405	30006112 + 83020938	Universal Adapter + Line Cord
DS Series	80500150 (obsolete)	80500151 (obsolete)	N/A (obsolete)	Rectangular 3Pin Power Adapter
E Series	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)	Power Adapter
EB / EC	<b>Snr &lt; 8033071417 or Old PCB:</b> 80120001 <b>New PCB or Snr &gt; 8033071417:</b> 46001812 + 46001779	<b>Snr &lt; 8033071417 or Old PCB:</b> 80120002 <b>New PCB or Snr &gt; 8033071417:</b> 46001812 + 46001779	<b>Snr &lt; 8033071417 or Old PCB:</b> 80120000 <b>New PCB or Snr &gt; 8033071417:</b> 46001812 + 46001780	Power Adapter or Universal Adapter + Plug Set
Emerald	2 x AAA Batteries	2 x AAA Batteries	2 x AAA Batteries	Batteries Only
ES Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Explorer / Explorer Pro	30006112 + 00087925	30006112 + 00089405	30006112 + 83020938	Universal Adapter + Line Cord
Explorer New (Ex models)	46001884 + 83020940	46001884 + 83020939	46001884 + 83020938	Universal Adapter + Line Cord
FD Series	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
G Series	00087925	00089405	00088668	Line Cord
GA Series	00087925	00089405	00088668	Line Cord
GT	00087925	00089405	00088668	Line Cord
HS / HP / HH	2 x AAA batteries	2 x AAA batteries	2 x AAA batteries	Batteries Only
I5S	80500061 (obsolete)	80500062 (obsolete)	-	Power Adapter
I10 / I20 / I20W	80500056 (obsolete)	80500057 (obsolete)	80500055 (obsolete)	Power Adapter
I150	00087925	00089405 (obsolete)	00088668	Line Cord
JR	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)	Power Adapter
JS	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
LS	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Mariner (MDxx)	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
MB23 / MB25	00087925	00089405	00088668	Line Cord
MB35 / MB45	00087925	00089405	00088668	Line Cord
MB200	00087925	00089405	00088668	Line Cord
MB300 / MB301	00087925	00089405	00088668	Line Cord
Mentor	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set

For additional assistance please contact [tsc@ohaus.com](mailto:tsc@ohaus.com)

Part numbers are subject to change without notice



# Adapter List 2013

Navigator (Old Model)	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Navigator (New Model)	46001724 + 46001779 <b>With Ethernet:</b> 46001802 + 46001779	46001724 + 46001779 <b>With Ethernet:</b> 46001802 + 46001779	46001724 + 46001780 <b>With Ethernet:</b> 46001802 + 46001780	Universal Adapter + Plug Set
Lume-O-Gram	9V, 150mA Adapter	9V, 150mA Adapter	9V, 150mA Adapter	
PBI	00087925	00089405	00088668	Line Cord
Pioneer Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
PS	00086320 (Batteries)	00086320 (Batteries)	00086320 (Batteries)	CR2032 Battery (2 Required)
Ranger (Without Battery)	22011363	22011365	22011364	Power Adapter
Ranger 3000	72200229	72200231	72200232	Line Cord
Ranger (With Battery)	22011300 + 00209918	22011300 + 22005261	22011300 + 00208835	Universal Adapter + Line Cord
RA Series	46001802 + 46001779	46001802 +	46001802 + 46001780	Universal Adapter + Plug Set,
RE Series	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
RH Series	00087925	00089405	00088668	Line Cord
RI Series	00087925	00089405	00088668	Line Cord
RS Series	71209768	72141528	-	Line Cord
RU Series	71209768	72141528	-	Line Cord
RV Series	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
RZ Series	TBD	TBD	TBD	
Ruby	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
S200	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Scout / Scout II	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Scout Pro	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
SD Series	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
SF40A	11107909 + 12120761	11107909 + 12120312	11107909 + 12120762	Universal Adapter + Line Cord
SF42	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
STP103	80252035 + 00087925	80252035 + 00089405	80252035 + 00088668	Universal Adapter + Line Cord
SRP275	80252034 + 00087925	80252034 + 00089405	80252034 + 00088668	Universal Adapter + Line Cord
TP	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)	Power Adapter
Traveler	46001724 + 46001779	46001724 + 46001779	46001724 + 46001780	Universal Adapter + Plug Set
Trooper	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set

For additional assistance please contact [tsc@ohaus.com](mailto:tsc@ohaus.com)

Part numbers are subject to change without notice



# Adapter List 2013

TS	80500138 (obsolete)	80500139 (obsolete)	80500137 (obsolete)	Power Adapter
UK149	80500208 (obsolete)	80500207 (obsolete)	N/A (obsolete)	Power Adapter
Valor 1000	46001812 + 46001779	46001812 + 46001779	46001812 + 46001780	Universal Adapter + Plug Set
Valor 2000	46001812 + 46001779	46001812 + 46001779	46001812 + 46001780	Universal Adapter + Plug Set,
Valor 3000	46001803 + 46001779	46001803 + 46001779	46001803 + 46001780	Universal Adapter + Plug Set,
Valor 5000	46001802 + 46001779	46001802 + 46001779	46001802 + 46001780	Universal Adapter + Plug Set
Valor 7000	72200229	72200231	72200232	Line Cord
Voyager / Voyager Pro	30006112 + 00087925	30006112 + 00089405	30006112 + 83020938	Universal Adapter + Line Cord
YA	2 x AAA Batteries	2 x AAA Batteries	2 x AAA Batteries	Batteries Only
YJ	80251915	80251917	80251906	Power Adapter (Option)
YS	80251915	80251917	80151906	Power Adapter

## Adapters

46001724	Adapter, Universal, 100-240V, 6W, 12V, 500mA,	Straight Tip (Old 420mA)
46001802	Adapter, Universal, 100-240V, 10W, 12V, 840mA,	Straight Tip
46001803	Adapter, Universal, 100-240V, 10W, 12V, 840mA,	Right Angle Tip
46001810	Adapter, Universal, 100-240V, 10W, 9V, 1120mA,	Straight Tip
46001812	Adapter, Universal, 100-240V, 10W, 12V, 840mA,	Right Angle Tip
46001884	Adapter, Universal, 100-240V, 18W, 12V, 1500mA,	Straight Tip

## Plugs & Plug Sets

46001779	Plug Set (EU, GB)
46001780	Plug Set (EU, GB, AU, US)

## Plugs

46001774	Plug (EU)
46001775	Plug (AU)
46001776	Plug (US)
46001777	Plug (UK)

For additional assistance please contact [tsc@ohaus.com](mailto:tsc@ohaus.com)

Part numbers are subject to change without notice